

# TORCTOOL

TOOL MODEL: TTX-7

## PRESSURE/TORQUE CONVERSION CHART

### Standard Torque Chart

PRESSURE IN PSI	TORQUE IN			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	1217	168	1650	104
1600	1301	180	1763	110
1800	1468	203	1991	124
2000	1636	226	2218	138
2200	1801	249	2442	152
2400	1967	272	2666	165
2600	2132	295	2891	179
2800	2298	318	3115	193
3000	2463	341	3339	207
3200	2633	364	3569	220
3400	2803	388	3799	234
3600	2972	411	4029	248
3800	3142	435	4259	262
4000	3312	458	4489	276
4200	3481	481	4719	290
4400	3651	505	4949	303
4600	3820	528	5179	317
4800	3990	552	5409	331
5000	4160	575	5639	345
5200	4332	599	5872	358
5400	4504	623	6105	372
5600	4676	647	6338	386
5800	4848	670	6571	400
6000	5020	694	6805	414
6200	5194	718	7041	427
6400	5368	742	7277	441
6600	5542	766	7513	455
6800	5716	791	7749	468
7000	5890	815	7985	482
7200	6065	839	8222	496
7400	6240	863	8459	510
7600	6415	887	8697	524
7800	6590	911	8934	538
8000	6765	936	9171	552
8200	6943	960	9411	565
8400	7120	985	9652	579
8600	7298	1009	9893	593
8800	7475	1034	10134	607
9000	7653	1058	10374	620
9200	7833	1083	10619	634
9400	8013	1108	10863	648
9600	8194	1133	11107	662
9800	8374	1158	11351	676
10000	8554	1183	11596	690