

TORCTOOL

TOOL MODEL: TTZ-14 W 312 HEX LINK PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart

PRESSURE IN PSI	FT. LBS.	TORQUE IN		PRESSURE IN BAR
		KGM	NM	
1500	2184	302	2961	104
1600	2333	323	3162	110
1800	2630	364	3566	124
2000	2928	405	3969	138
2200	3228	446	4376	152
2400	3528	488	4783	165
2600	3828	529	5189	179
2800	4128	571	5596	193
3000	4428	612	6003	207
3200	4726	654	6407	220
3400	5025	695	6812	234
3600	5323	736	7216	248
3800	5622	777	7621	262
4000	5920	819	8025	276
4200	6222	860	8434	290
4400	6524	902	8843	303
4600	6825	944	9253	317
4800	7127	986	9662	331
5000	7429	1027	10071	345
5200	7729	1069	10478	358
5400	8030	1111	10885	372
5600	8330	1152	11292	386
5800	8631	1194	11700	400
6000	8931	1235	12107	414
6200	9242	1278	12528	427
6400	9553	1321	12950	441
6600	9863	1364	13371	455
6800	10174	1407	13792	468
7000	10485	1450	14213	482
7200	10776	1490	14608	496
7400	11067	1531	15002	510
7600	11358	1571	15397	524
7800	11649	1611	15791	538
8000	11940	1651	16186	552
8200	12242	1693	16595	565
8400	12544	1735	17005	579
8600	12846	1777	17414	593
8800	13148	1818	17823	607
9000	13450	1860	18233	620
9200	13748	1901	18637	634
9400	14046	1943	19041	648
9600	14345	1984	19446	662
9800	14643	2025	19850	676
10000	14941	2066	20254	690