

TORCTOOL

TOOL MODEL: TTZ-4 W 205 HEX LINK SN T4EA1242-004

PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart

PRESSURE IN PSI	TORQUE IN			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	607	84	823	104
1600	647	89	877	110
1800	726	100	985	124
2000	806	111	1093	138
2200	893	124	1211	152
2400	981	136	1330	165
2600	1068	148	1448	179
2800	1156	160	1567	193
3000	1243	172	1685	207
3200	1328	184	1800	220
3400	1413	195	1915	234
3600	1498	207	2031	248
3800	1583	219	2146	262
4000	1668	231	2261	276
4200	1750	242	2372	290
4400	1832	253	2483	303
4600	1913	265	2594	317
4800	1995	276	2705	331
5000	2077	287	2816	345
5200	2163	299	2932	358
5400	2249	311	3049	372
5600	2336	323	3166	386
5800	2422	335	3283	400
6000	2508	347	3400	414
6200	2597	359	3521	427
6400	2686	372	3642	441
6600	2776	384	3763	455
6800	2865	396	3884	468
7000	2954	409	4004	482
7200	3040	420	4122	496
7400	3127	432	4239	510
7600	3213	444	4356	524
7800	3300	456	4473	538
8000	3386	468	4590	552
8200	3472	480	4707	565
8400	3558	492	4823	579
8600	3644	504	4940	593
8800	3730	516	5056	607
9000	3816	528	5173	620
9200	3915	541	5307	634
9400	4013	555	5440	648
9600	4112	569	5574	662
9800	4210	582	5708	676
10000	4309	596	5841	690